

Home / Other Products / Sharpener / Sharpener

#### **Sharpener**

Sharpener

Item No.: KG048



Description

**Quotation Information** 









Product: Sharpener
Size: 23.7x5x6.6cm
Weight: 190g
Material: ABS, TPR, ZrO2,
18/0 Stainless Steel,
Carborundum

- - - - - - - - - - - Size - - - - - - - - -



#### ----- Details -----

- 01 Beautiful back pad, luxury, gorgeous, splendid and posh
- O3 Ergonomic handle, to provide best sharpening experience
- O2 Anti-slip ground mat, make sharpener stable, safe is most important
- 04 Three section of knife grinding, combining fine grinding and rough grinding







#### Directions for use

#### 01 Rough grinding

Put blade into rough grinding side, pull knife blade back and forth in constant speed, repeat 3-5 times




Rough grinding is suitable for rough blade knife or the knife using long time but not grind yet

Generally, suit for cleaver knife, chef knife, carving knife and paring knife

The width of knife grinding edge is 5MM, about 2 corns thickness, Chopping knife's blade is thicker, so it depends

### 02 Grinding

Put blade into grinding side, pull knife blade back and forth in constant speed, repeat 3-5 times




Suitable for rough blade knife or the knife using long time but not grind yet

Generally, suit for cleaver knife, chef knife, carving knife and paring knife

The width of knife grinding edge is 5MM, about 2 corns thickness, Chopping knife's blade is thicker, so it depends on the knife when using the sharpener

## 03 Fine grinding

Put the blade into the fine grinding side, pull knife blade back and forth in constant speed, repeat 3-5 times



Fine grinding side used special ceramic raw material, have nice grinding feature.

Generally use to be repaired the rag after rough grinding, makes the blade more smooth.

Using ceramic side for grinding regularly will extend service life of knife.

# **Q**き品 Warm Prompt

- 1. This product is not suitable for grinding scissors, serrated knife and ceramic knife.
- 2.Not too hard when sharpening the knife in case damaging knife blade.
- 3.Not to put the sharpener into wash machine or water.
- 4. Sharpener and knife should put on the place which children can not touch easier in case accident.